










Part List


W3012BGFI


Unit: inch

No	Picture	Specification	Qty
A		Screw $\varnothing 3 \times 1 \frac{1}{2}$ "	32
B		Screw $\varnothing 3 \times 5 \frac{7}{8}$ "	8
C		Screw $\varnothing 4 \times 5 \frac{7}{8}$ "	4
D		Screw $\varnothing 4 \times 1 \frac{3}{16}$ "	6
E		Corner Bracket	8
F		Hinges	4
G		Bumper	4

1  Left Door	2  Right Door	3  Face Frame
4  Left Side Panel	5  Right Side Panel	6  Top Panel
7  Bottom Panel	8  Back Panel	
		 A B C D

Assembly instructions

No	Picture	Specification	Qty	No	Picture	Specification	Qty
A		Screw Ø3*1/2"	32	E		Corner Bracket	8
B		Screw Ø3*5/8"	8	F		Hinges	4
C		Screw Ø4*5/8"	4	G		Bumper	4
D		Screw Ø4*1 3/16"	6				



page 1 of 1

W2412-W3612 W331224-W361224

W2415-W3615 W331524-W361524

W2418-W3618 W331824-W361824

